

How to add a headrest

Tools required:

- Power drill
- 3/16" drill bit

Remove back panel



Step 1

Pull the two clips (1) located inside the back panel in opposite directions at the same time. This will unclip the bottom portion of the panel.



Step 2

Place four fingers under the panel, then push the back frame with thumbs to release the second clip (2).



tCentric Hybrid™ Mesh Backrest



Step 3

Locate the two pre-marked dots at the top left and right of the released panel. Drill holes through the dots using 5mm (3/16") drill bit.

Do not worry about the quality of the holes drilled, they will be completely covered by the headrest.



Notch

Step 4

Snap the panel back in by placing notches into the grooves at the top of the backrest, then snap in the bottom clips followed by the center clip.



Step 5

Align the new headrest bracket with the drilled holes and install the provided M6x25mm pan head fasteners, secure the headrest to the back of the chair.

