
Assembly Instructions



ergoCentric

U x8


Parts



Preparing the tabletop


Step 1a: Lay tabletop on floor or work area with decorative laminate faced down and brown underside faced up.

Step 1b: Identify your tabletop size.




Assembly Instructions

Step 2: Align under-table support (**A**) with pilot holes and secure with #8x7%" (**B**) wood screws.




Step 3: Assemble Brackets

Step 2a: Snap Part 1 and Part 2 of the Release Assembly (**C**) together, ensuring that the holes align according to your tabletop size.





Step 3b: Press the Release assembly into the designated groove within the Folding Bracket (**D**).

Step 3c: Insert the white plastic Vertical Lock (**E**) into the rectangular cutout. Press until the top surface is flush with the Folding Bracket.



Step 2d: On the bottom side of the Folding Bracket, insert the Wedge (**F**) piece into the outer hole of the rectangular slot. Apply pressure until secured.






Step 4: Attach Bracket


Secure the Folding Bracket to the leg (**G**) using M10 washer (**H**) and bolt (**I**) provided. Ensure that the leg is squared up with the bracket and that the pilot holes are situated on the side nearest the release cylinder, as shown.

Step 5: Assemble Frame


With the folding bracket fastened to the leg, turn both leg assemblies upside down and release the legs so they are in the folded down position.


Set leg assemblies on underside of tabletop and slide either end of release bar (**J**) into folding brackets.






Step 7: Attach both male (**O**) and female (**P**) ganging connectors to folding machanism using inserts (**Q**), and screws (**R**).






Step 7a: Attach ganging connectors to outer edge of each Release Assembly.

Step 8: Unscrew both glides from each foot, then screw in casters (**S**).





Step 9: Place foot upside down on the bottom of the leg tube so that the long edges of the foot and folding mechanism run paralell to each other.

Attach feet (**T**) to leg (**G**) using bolts (**U**).



ergoCentric

ph: 1 866 GET ERGO (438-3746) | 905 696-6800 fx: 1 800 848-5190 | 905 696-0899 service@ergocentric.com ergocentric.com

ergoCentric® is a registered trademark of ergoCentric Inc.